

RACEAIR™ PRO
COMPETITION WEATHER ANALYZER AND COMPUTER
USER'S MANUAL for v2



COPYRIGHT 2002
COMPUTECH SYSTEMS, INC.
29962 KILLPECK CREEK COURT
CHARLOTTE HALL, MD 20622

email: computech@ameritel.net

QUICK START GUIDE

1. Make sure batteries are installed.
2. Press **POWER ON/OFF** key.
3. Press **SAMPLE** key to take weather sample.
4. Use left side black and red keys to access programs. Press **ALT** first for red programs.
5. Use down arrow (**NO**) key or up arrow (**YES**) key to move the display left indicator arrow to navigate program menus.
6. Press **ENTER** to use program.
7. Answer program questions (?) to calculate result.

CONTENTS

COMPUTER PROGRAM CAPABILITIES	Page 3
GENERAL INFORMATION	Page 9
Power Requirements.	Page 9
Keyboard Functions.	Page 9
Program Access and Use.	Page 10
Communication Port.	Page 10
Program Updates.	Page 11
Additional Instructions	Page 11
COMPETITION WEATHER ANALYZER	Page 11
Overview	Page 11
Weather Terms.	Page 11
Good Air / Bad Air.	Page 14
Sampling Information.	Page 15
Calibration	Page 15
Specifications	Page 16
Weather Analyzer Operation.	Page 16
COMPUTER PROGRAMS OPERATION	Page 17

COMPUTER PROGRAM CAPABILITIES

This list is indented to show access menu levels. Refer to **Program Access and Use**.

TUNE-UP key

Page 17

1 Jetting Menu

1 Holley

Page 18

This program will calculate the proper Holley carburetor jet to use based on a change in weather conditions. It also allows the user to adjust the air/fuel ratio to achieve the proper engine tune.

2 Prec Jets

Page 19

This program will calculate the proper jet diameter, in inches or millimeters, to use based on a change in weather conditions for any carburetor. It also allows the user to adjust the air/fuel ratio to achieve the proper engine tune.

3 Mikuni Jets

Page 19

This program will calculate the proper Mikuni carburetor jet to use based on a change in weather conditions. It also allows the user to adjust the air/fuel ratio to achieve the proper engine tune.

4 Keihin Jets

Page 19

This program will calculate the proper Keihin carburetor jet to use based on a change in weather conditions. It also allows the user to adjust the air/fuel ratio to achieve the proper engine tune.

5 Injection

Page 20

This program will calculate the proper continuous flow mechanical fuel injection main jet (pill) to use based on a change in weather conditions using jet and nozzle areas. It allows the user to adjust the air/fuel ratio to achieve the proper engine tune. Additionally, a fuel rail pressure change is calculated for use in adjusting a high speed lean out system relief valve.

6 F/G Injection

Page 21

This program will calculate the proper continuous flow mechanical fuel injection main jet (pill) to use based on a change in weather conditions without knowing the injector nozzle sizes. It also allows the user to adjust the air/fuel ratio to achieve the proper engine tune.

7 High Speed

Page 21

This program will calculate a bypass flow jet change for a continuous flow mechanical fuel injection high speed lean out system.

8 Square Area

Page 22

This program will easily calculate the area of several nozzles or jets and provide a single orifice diameter equivalent.

2 Blower OD

Page 22

This program will calculate blower drive speed in relation to crankshaft speed based on pulley tooth count or circumference.

3 Meth. Spec.

Page 23

This program is used in conjunction with a hydrometer and thermometer to correct the specific gravity of methanol when checking for moisture contamination.

4 Gas. Spec.

Page 23

This program is used in conjunction with a hydrometer and thermometer to correct the specific gravity of gasoline.

5 Nitro %

Page 23

This program is used in conjunction with a hydrometer and thermometer to determine the corrected nitro percentage of a measured sample.

6 EGT Correct'n

Page 24

This program will correct the indicated or observed engine exhaust gas temperature (EGT) for variations in engine air inlet temperature. The corrected EGT value can be used as a tuning aid.

7 EGT Predict'n

Page 24

This program will calculate the indicated or observed engine exhaust temperature (EGT) from a corrected EGT and the current engine air inlet temperature.

DIAL-IN key

1 Standard

Page 25

*This program will predict an elapsed time (ET) dial-in, for 1/8 and 1/4-mile Drag Racing, based on 1 previous good run and the change in horsepower correction factor due to a weather change. **Note:** This program requires changing the fuel selection in **SET-UP, Program Setup, Fuel Setup** when using methanol.*

2 Density Altd

Page 26

This program will predict an elapsed time (ET) dial-in based on 3 previous good runs and the change in density altitude due to a weather change.

T-STOP key

Page 27

This program will calculate the throttle closed timer setting to produce a desired elapsed time (ET) based on 2 previous runs, 1 faster than the index and 1 slower than the index. The program capacity allows data storage for 3 different cars or 3 different indexes.

DRAG FORMULAS key

1 Gear Ratio

Page 29

This program will calculate the vehicle gear ratio based on tire size, MPH, engine RPM, and torque converter slip.

2 Trap RPM

Page 29

This program will calculate the trap engine RPM based on tire size, MPH, gear ratio, and torque converter slip.

3 Converter Slip

Page 30

This program will calculate the torque converter slip RPM and percentage based on tire size, MPH, engine RPM, and gear ratio.

CIR.TRK. FORMULAS key

1 Gearing/Tires

1 Engine RPM

Page 33

This program will calculate the resulting engine RPM change with tire size and gear ratio changes.

2 Gear Ratio

Page 33

This program will calculate the proper gear ratio to compensate for changes in tire size and desired engine RPM.

3 Tire Size

Page 34

This program will calculate the proper tire size to compensate for changes in gear ratio and desired engine RPM.

4 MPH Calc

Page 37

This program will calculate the vehicle MPH based on engine RPM, gear ratio, and tire size.

5 Tire Stagger

Page 34

This program will suggest a tire stagger condition based on track measurements.

2 Chassis

1 Setup by Pct

Page 34

This program will calculate the scale weights for each wheel from total vehicle weight and requested front, rear, and diagonal weight distribution percentages.

2 Setup by Wgt

Page 35

This program will calculate the front, rear, and diagonal weight distribution percentages from actual scale weights for each wheel.

3 Fuel Mileage

Page 35

This program will calculate fuel mileage from pit stop measurements, predict when the next fuel stop should be made, and calculate the fuel required to finish the race.

4 Liquid Wgts

Page 36

This program will calculate the weight of water, methanol, and gasoline when the quantity in gallons is entered.

ALT - AIR CORR. key

Page 17

This program will calculate the horsepower correction factor, density altitude, air density ratio (ADR), dry barometer, wet bulb temperature, dew point, partial vapor pressure, water vapor grains, and pressure altitude from an input of temperature, relative humidity, and absolute barometer. Use this program to calculate weather data when taking an actual air sample is not desired (i.e. from logbook entries of temperature, relative humidity, and barometric pressure or evaluating other than sampled conditions).

ALT - RUN COMP key

Page 30

This program will estimate the 1/8 or 1/4 mile elapsed time (ET) and MPH for a run where the throttle was closed before the finish line. The program uses information from a previous full pass to predict performance.

ALT - DRAG PERF key

1 Full Run Std

Page 30

This program will correct observed finish line elapsed time (ET) and MPH performance to Standard Day weather conditions. This information can be used to compare runs done on different days to evaluate vehicle changes or driving techniques.

2 Intermed. Run

Page 31

This program will correct observed 60', 330', 660', 1000', and 1320' elapsed times (ETs) to Standard Day weather conditions. This information can be used to compare runs done on different days to evaluate vehicle changes or driving techniques.

3 Est. 1/8 HP

Page 32

This program will estimate the horsepower output required to move the vehicle to the 660' track marker based on vehicle weight and elapsed time (ET). It will also adjust horsepower corrected to Standard Day weather conditions.

4 Est. 1/4 HP

Page 32

This program will estimate the horsepower output required to move the vehicle to the 1320' track marker based on vehicle weight and elapsed time (ET). It will also calculate horsepower corrected to Standard Day weather conditions.

5 Est. ET/MPH

Page 32

This program will estimate the 1/8-mile elapsed time (ET) and MPH plus the 1/4-mile ET and MPH from engine horsepower and vehicle weight.

ALT - ENGINE FORMULAS key

1 C/R Menu

1 Calc Ratio

Page 37

This program will calculate engine compression ratio from cylinder bore, crankshaft stroke, combustion chamber volume, and piston dome volume. Piston deck height, head gasket volume, and supercharger boost pressure are included in the equation.

2 Calc Chamber

Page 38

This program will calculate the required combustion chamber volume from cylinder bore, crankshaft stroke, and piston dome volume when a compression ratio is specified. Piston deck height, head gasket volume, and supercharger boost pressure are included in the equation.

3 Calc Dome

Page 38

This program will calculate the required piston dome volume from cylinder bore, crankshaft stroke, and combustion chamber volume when a compression ratio is specified. Piston deck height, head gasket volume, and supercharger boost pressure are included in the equation.

4 Pour Chamber

Page 39

This program will calculate the engine compression ratio using the cylinder bore, crankshaft stroke, and the measured liquid volume poured into the combustion chamber of an assembled engine with the piston on top dead center (TDC).

5 Pour Dome

Page 39

This program will calculate the effective piston dome volume by measuring the piston deck height, installing a clear plastic plate in place of the cylinder head, then measuring the poured liquid volume in the void.

2 C.I.D. Menu

1 Calc C.I.D.

Page 40

This program will calculate engine displacement in cubic inches and liters from cylinder bore, crankshaft stroke, and the number of cylinders.

2 Calc Bore

Page 40

This program will calculate the cylinder bore required for a specified engine displacement when crankshaft stroke and the number of cylinders are given.

3 Calc Stroke

Page 40

This program will calculate the crankshaft stroke required for a specified engine displacement when cylinder bore and the number of cylinders are given.

ALT - SET-UP key

1 Program Setup

1 Fuel Setup

*This program is used to set the fuel type (gasoline, methanol, or special) in the **Std. Dial-In**, the **Full Run Std**, and the **Intermed. Run** programs. The default setting is gasoline. Press the down arrow key to view the other fuels then press **ENTER** to select that fuel. The proper fuel factor is automatically set into the programs when gasoline or methanol is selected. To compensate for other fuels or to use another factor, press the down arrow key until **Special** is displayed then press **ENTER**. The display will show **Factor?**. Press in the desired multiplication factor and press **ENTER**. For example, a fuel factor that is 10% less than the standard would be 0.90.*

2 T-Stop Setup

*This function is discussed in the **Throttle Stop** program. It only needs to be done to predict throttle stop timer settings.*

3 D.A. Setup

*This function is discussed in the **Density Altd Dial-In** program. It is used to determine the slope of run data for that program.*

4 SAE HP vs. STD

*This function changes the horsepower correction method from Standard to SAE. The default setting is **STD**. When the **SAE HP? NO** line is displayed, press **ENTER** to cause the cursor block to flash then **YES** to change to the new SAE correction factor.*

2 Factory Setup

1 Set Clock

This program is used to set the date and time.

2 Show Calib.

This screen is for factory use to show the weather sensors calibration file.

3 Factory Reset

*This program will remove the weather sensor calibration file from the computer memory. **DO NOT use this program** without specific instructions from Computech on how to save the calibration file.*

4 Empty Recycle

*This program can be used when the **Loading User Memory...** Message remains on the screen for several seconds. Emptying the recycle bin will speed up the computer operation.*

5 Clr User Mem

This function is not normally used. Clearing the user memory will reset all computer variables to 0. All set-up functions will need to be reentered.

Battery=

This line indicates the measured voltage in the computer circuit. When on battery power, it can show when the batteries are getting weak.

3 Calculator

*This program is a 4 function calculator (i. e. add, subtract, multiply, and divide). The + key (**YES**) and the - key (**NO**) are used to add and subtract. To multiply, press **ALT** then + or to divide press **ALT** then --. Press **ENTER** to see the answer.*

Important: *The calculator can be accessed from within any program by pressing **ALT** then **ENTER**. The calculator function will remember the number from the computer program line where the left indicator arrow is positioned. The calculator functions can then be used with that number. The computer will insert the new calculated value back in the program line by pressing **ALT** then **ENTER** again.*

Dynamometer Horsepower Correction

The = **Sampled Wthr** = screen can be used to quickly correct observed dyno torque and horsepower values. Press the **SAMPLE** key and place the *RaceAir Pro* near the engine air intake. Allow the unit to finish sampling. Make sure the left side indicator arrow is on the **STD Corr=** (or **SAE Corr=**). Press **ALT** then **ENTER** to transfer the correction factor to the calculator. Press **ALT** then + (to multiply). Press in the observed number (torque or horsepower) and press **ENTER** to see the corrected value. Pressing **ALT ENTER** again will send the computer back to the = **Sampled Wthr** = screen. The process can be repeated again for the next value. The same technique can be used for previously recorded weather conditions using the **AIR CORR.** program.

GENERAL INFORMATION

Power Requirements.

The *RaceAir Pro* uses 6 AA batteries. Note the polarity markings on the battery tray when installing the batteries. The unit will automatically turn off after 10 minutes of inactivity. The highest current draw on the batteries is the fan that comes on when the air **SAMPLE** key is pressed. Use the display **LIGHT** only as necessary, to preserve battery life. The computer will display a caution message when the battery voltage is too low for acceptable operation. If the display stops responding to keystrokes, including the **POWER ON/OFF** key, it may be necessary to remove and reinstall the batteries to restart the computer.

The computer may also be powered with a 12-V dc adapter through the upper connector provided on the left side of the case. The 110-V ac to 12-V dc adapter is available from Computech Systems, Inc. The unit may be safely powered by the adapter while the batteries are installed.

Keyboard Functions.

The keyboard has several multifunction keys. The **YES** key also functions as an up arrow key and a + (plus) key. The **NO** key functions as a down arrow key and a -- (minus) key. The split black and red keys have 2 functions. When a black and red key is pressed the computer will go to the function labeled in black. When the red **ALT** key is pressed then a black and red key is pressed the computer will go to the function labeled in red.



The **POWER ON/OFF** key must be pressed and momentarily held to turn on the computer.

The **ENTER** key is discussed in **Program Access and Use** below.

The **CLEAR** key may be used anytime to exit a menu or program. **CLEAR** is also used to backspace an incorrect entry.

When the computer is powered, pressing the red **SAMPLE** key will turn on the fan and take a weather sample. The weather sampling process may be aborted by pressing **SAMPLE** again. Several of the included programs use weather information in the calculations. When a program asks for current weather information, pressing the **IMPORT WEATHER DATA** key will automatically transfer that data. The *RaceAir Pro* powers up in the **==Live== Fan OFF** mode. The actual air data from the last sample may be viewed by pressing **ALT** then **IMPORT WEATHER DATA**.

Program Access and Use

The COMPUTER PROGRAM CAPABILITIES list can be used to select a program. The list is indented to show the access menu levels. The indicator arrow on the left side of the display may be repositioned in a menu or in a program screen by pressing the up or down arrow keys. The up and down arrow keys will repeat or continue to move the indicator arrow when held. Pressing the **ENTER** key will make the computer go to the item where the left indicator arrow is positioned.

An alternate quick program access method is to use the number shown to the left of a program. For example - to access the **Holley** carburetor jetting program, press **TUNE-UP**, then **1** to access the **Jetting Menu**, then **1** again to get to the **Holley** program.

When a program needs a user input a **?** will appear at the end of a statement. A number from the computer memory may appear after the **?**. Either accept this number by pressing **ENTER** or press in a new number on the keyboard then press **ENTER**. When an answer is presented, an **=** will appear at the end of the statement. A blinking cursor block will appear on the right side of a statement when the computer is expecting a user input.

Recalculate Function. The up and down arrow keys may be used to reposition the left side indicator arrow to a program input line. Pressing **ENTER** will open that input and show a blinking cursor block to accept a new entry. It is not necessary to restart the program from the beginning to calculate a new answer.

Communication Port.

The lower of the 2 ports on the left side of the computer is for communication with a personal computer (PC). The optionally available Computech *Weather Pro* software will interface with the *RaceAir Pro*. When the communications link is established, the sensors in the *RaceAir Pro* send information to the PC that is running the *Weather Pro* program. The *Weather Pro* calculates the various air conditions, logs the information, and presents a graphic view of what the weather is doing. A weather file is saved for future reference. The *Weather Pro* software, with the required cables and power supply, is available from Computech Systems, Inc.

Additionally, the Comm port is used to update the *RaceAir Pro* program firmware. An interface kit is available from Computech Systems, Inc. to perform these updates. The kit contains the PC



interface software, the PC to *RaceAir Pro* interface cable with serial adapter, and a power supply.

Program Updates.

The *RaceAir Pro* program firmware is user updateable with the optional PC interface kit. The latest version of the program will be posted on the Computech Systems, Inc. web site: www.computechracing.com The downloads are free for the life of the computer. As changes or additions are made to the program, new files will be posted on the web site. The *RaceAir Pro* may be sent back to Computech Systems, Inc. for program updates, if desired.

Additional Instructions

Please take the time to read each program operation so that you can utilize the *RaceAir Pro* System to the fullest. Should you need personal assistance, contact the Computech technical department anytime between 9:00 a.m. to 5:00 p.m. eastern time, Monday through Friday.

Tech Line: 301-884-5712 Fax: 301-884-5763

email: computech@ameritel.net

COMPETITION WEATHER ANALYZER

Overview

The weather analyzer contained in the *RaceAir Pro* measures the air quality. It is based on the air temperature in degrees Fahrenheit (°F), the relative humidity in percent (%), and the absolute barometric pressure in inches of mercury (Inches Hg). Subtle changes in any of these variables can have an impact on the performance of your vehicle. This portion of the *RaceAir Pro* will provide you with: the STD or SAE HP Correction Factor, Density Altitude (ft), Air Density Ratio (%), Dry Barometer pressure (Inches Hg), Dew Point temperature (°F), Wet Bulb Temperature (°F), water Vapor Pressure (Inches Hg), and Pressure Altitude (ft).

Weather Terms. This list is in alphabetical order.

Air Density Ratio

Air density ratio (ADR) is the ratio produced by dividing the calculated density of the air being sampled by the Standard Day air density. Standard Day air is defined as a temperature of 60°F, a relative humidity of 0%, and an absolute barometric pressure of 29.92 In. Hg. The ADR for those conditions is 1.00. The *RaceAir Pro* expresses this ratio as a percent, Standard Day = 100%, as an aid to understanding the performance increases and decreases that air density causes. Air Density Ratio is used to determine engine fuel tuning changes. If the ADR goes down 2%, then fuel must be reduced 2% to stay at the same air/fuel ratio.

Absolute Barometric Pressure

Absolute barometric pressure, measured in inches of mercury (Inches Hg), is the pressure that is present at the location of the sensor from the atmosphere. The term 'barometric' comes from the weather instrument, the mercury barometer, which is used as a laboratory precision measuring device. The term 'absolute' refers to absolute zero, where without the earth's atmosphere, the measured pressure would be 0 Inches Hg. Normal pressure gages have a scale that sets the atmospheric pressure of 14.7 pounds per square inch (29.92 Inches Hg) as the zero point. This is referred to as gage pressure. The *RaceAir Pro* provides the absolute barometric pressure that is used in the calculations for ADR, Density Altitude, and the Correction Factor. It has the biggest influence on air quality. Absolute barometric pressure normally varies between 25 and 31 Inches Hg depending on the elevation above sea level where the sensor is. The atmospheric pressure defined as Standard Day at sea level is 29.92 Inches Hg and decreases about 1 Inch Hg per 1000 ft. of elevation.

Altitude

Altitude is the elevation above mean sea level (MSL) in feet.

Altitude – Density

See 'Density Altitude'.

Altitude – Pressure

See 'Pressure Altitude'.

Barometric Pressure - Absolute

See 'Absolute Barometric Pressure'.

Barometric Pressure - Corrected to Sea Level

In order to provide a standard method of stating barometric pressure, the National Weather Service (NWS) adjusts the absolute barometric pressure observations to sea level elevation (0 feet). Without this standard the barometer readings would be meaningless at different geographic elevations around the world. The correction adds about 0.001 Inches Hg per foot of elevation to the absolute barometric pressure number. Corrected barometric pressure cannot be used for performance calculations without subtracting the local elevation from the NWS value. Even then it would be an approximation because the barometer is at another location.

Barometric Pressure - Dry

See 'Dry Barometric Pressure'.

Correction Factor

The correction factor is a Society of Automotive Engineers (SAE) equation that uses the calculated dry barometric pressure and the measured local temperature to compensate for changes in dynamometer observed horsepower readings due to air density differences. This method allows performance comparison of observed readings taken on different days or in different parts of the world. The correction factor can also be applied to track performance. There are 2 correction factor equations in common use in the industry - the current SAE and STD or the old SAE standard. The STD and SAE methods also have different reference points (where correction factor 1.000 occurs). Therefore, values corrected with one method cannot be compared to values corrected by the other.

Density Altitude

Density altitude is a value in feet that relates the local measured atmospheric conditions (absolute barometric pressure or pressure altitude, temperature, and relative humidity) to the aeronautical industry defined standard day atmosphere. The density altitude for an absolute barometric pressure of 29.92 Inches Hg or a pressure altitude of 0 ft, a temperature of 60°F, and a humidity of 0% is 0 ft. A good air day in the spring or fall might be below 0 ft (i.e. -831 ft). Conversely, a hot summer day might have a density altitude of 4500 ft. (equivalent to 4500 ft of altitude on a standard day).

Dew Point

The dew point temperature is the calculated temperature at which the measured partial saturation of water vapor in the air will turn to liquid and form dew. Moisture can cause inconsistent traction and, in certain circumstances, effect engine performance. The warmer the air is the more water vapor it can hold. See 'Relative Humidity' for more information. An air sample has a specific amount of water vapor present. As the temperature drops and reaches the dew point, the air can no longer hold the water vapor suspended so it condenses and turns to water. This condensation will occur on cooler surfaces first. Computech research with methanol fuel, and to a lesser extent with gasoline, has shown that when the ambient temperature falls to within 5 to 10°F of the dew point temperature there will be an unexpected slight fall off in performance due primarily to fuel degradation in the intake manifold that is caused by water contamination. By keeping accurate records as to when the performance actually falls off in relation the outside temperature versus the dew point temperature, performance degradation can be predicted.

Dry Barometric Pressure

The dry barometric pressure (Inches Hg) is the absolute barometric pressure with the partial saturation water vapor pressure from humidity subtracted. The measured absolute barometric pressure is from a combination of oxygen, nitrogen, argon, and some other trace gases plus water vapor. The portion of the air that is water vapor will not contribute to combustion of the fuel and therefore must be factored out. Dry barometric pressure is used to calculate ADR, Density Altitude, and the Correction Factor.

Dry Bulb Temperature

See 'Temperature'.

Pressure Altitude

Pressure altitude is the aircraft altimeter indicated value in feet that results from setting the pressure adjustment window to 29.92 Inches Hg. This number relates to the aeronautical industry defined Standard Day altitude. An indication of 0 ft is equal to an absolute barometric pressure of 29.92 Inches Hg. Lower or negative values (i.e. -180 ft) indicate more air pressure. Higher values (i.e. 2500 ft) show less air pressure. An altimeter will also show absolute barometric pressure (Inches Hg) in the pressure window when the altitude pointer is rotated to indicate 0 ft. Note that this number is pressure only. Until it is adjusted for temperature and humidity via the density altitude process it is not an indication of total air quality.

Relative Humidity

Relative humidity (% RH) is a value to indicate how much water vapor is present in an air sample. Air has the ability to hold more water vapor as the temperature increases. This phenomenon makes comprehending water vapor content difficult. By always relating the amount of water vapor present to the maximum amount that air could hold at that temperature, the relationship is easier to understand (i.e. 50% RH is always 50% of the possible saturated water vapor content for air at any temperature).

Temperature

Temperature (°F) is also referred to as dry bulb temperature. In order to correctly calculate the effect of temperature on performance, the measured temperature needs to be similar to the engine intake air temperature.

Vapor Pressure

Vapor pressure (Inches Hg) is a value calculated from the sensed temperature and relative humidity. The *RaceAir Pro* uses numbers derived from mechanical engineering steam tables to calculate the partial saturation vapor pressure of the moisture in the sampled air. That value is displayed and used in the 'Dry Barometric Pressure' computation. The vapor pressure number indicates the portion of air pressure that is actually from water vapor and, of course, will not support combustion.

Water Vapor

Water vapor (grains, Gr) is the same information as 'Vapor Pressure' expressed in different units. Some race teams use 100 Gr as the threshold for making water vapor related tuning changes. Engine fuel flow and ignition timing may need to be increased above the threshold.

Wet Bulb Temperature

Wet bulb temperature refers to using an expanding liquid type thermometer with a water soaked cotton wick over the sensing bulb. This technique produces a lower temperature indication for lower humidity conditions due to evaporation. The wet bulb temperature and the dry bulb temperature can be used to calculate 'Relative Humidity'.

Good Air / Bad Air.

The atmospheric conditions that make air quality better for racing are: lower temperature, lower humidity, and higher air pressure. Conditions that make the air worse for racing purposes are: higher temperature, higher humidity, and lower air pressure. Lower Correction Factor numbers, lower Density Altitude numbers and higher Air Density Ratio numbers all mean better air quality.

The variables that cause the Correction Factor and the Density Altitude to decrease (smaller numerically), as well as the Air Density Ratio to increase (larger numerically), are: a lower temperature, a lower relative humidity, a higher barometric pressure (as measured with a barometer), or a lower pressure altitude (as measured with an altimeter). Typically, the STD Correction Factor will be between .98 (better) and 1.15 (worse); the Density Altitude will be between -300 ft. (better) and 8,000 ft. (worse); the Air Density Ratio will be between 85% (worse) and 103% (better).

Atmospheric changes can be experienced when going from track to track or from Spring to Summer to Fall at the same track. The typical change in air quality from the heat of the day to

the cool of the night is usually not very large. However, the *RaceAir Pro* will compensate for changes in all of the weather variables, no matter how small.

Remember, as the Correction Factor and the Density Altitude increase (larger numerically), performance will decrease. As the Correction Factor and Density Altitude decrease (smaller numerically), performance will increase. The lower the Air Density Ratio (smaller numerically), the leaner the jetting needs to be and the higher the Air Density Ratio (larger numerically), the richer the jetting needs to be.

Sampling Information.

The top portion of the *RaceAir Pro*, where the red stripe is, contains the weather sensors. During the sampling process, air is drawn in through the diagonal slits in the faceplate by the internal fan. The air is then exhausted through the vents on the upper left side of the case. These air passages must remain clear for accurate measurements. Also, the temperature, humidity, and pressure readings may not be accurate when the fan is not operating.

When the **SAMPLE** key is pressed, the *RaceAir Pro* automatically samples current weather conditions, locks in a set of good sample readings, and then displays those readings along with a number of calculated weather values. These values may be used independently, or in conjunction with the programs contained within the *RaceAir Pro* computer for accurate performance prediction and tuning assistance.

Important: Air samples should be taken at approximately engine air intake height above the same type of surface as the racetrack (i.e. dirt, asphalt, or concrete). Keep the unit out of direct sun and away from engine exhaust or other heat sources while sampling. Also, keep your body heat away from the intake vents on the front. Use the *RaceAir Pro* the same way each time an air sample is taken. When in use, keep the *RaceAir Pro* in an environment similar to that being sampled. For example, don't pull the *RaceAir Pro* directly out of a hot trailer and immediately take a sample. The amount of time required for such a sample to stabilize is significantly longer than normal and the result could be less accurate. The sampling process will typically take between 15 seconds to 3 minutes.

Don't allow water to enter the vents in the front or on the left side. If this happens or if the display appears confused, remove the batteries and allow the *RaceAir Pro* to dry out!

Calibration

Each *RaceAir Pro* goes through a rigorous calibration process to assure the highest accuracy of the readings. The calibration data is unique to each unit. The data is stored in the computer memory with an internal battery backup so the weather sensor corrections are not lost during battery changes. Under normal operating and storage conditions, it is not necessary to have the unit periodically recalibrated.

Specifications

- Display Resolution: Temperature: 0.1 degree F
 Relative Humidity: 1%
 Absolute Barometric Pressure: 0.01 Inches of Mercury
- Internal Resolution: Temperature: 0.01 degree F
 Relative Humidity: 0.1%
 Absolute Barometric Pressure: 0.003 Inches of Mercury
- Accuracy: Temperature: +/- 1.2 degree F
 Relative Humidity: +/- 3%;
 Absolute Barometric Pressure: +/- 0.05 Inches of Mercury
- Repeatability: Approximately equal to display resolution

Weather Analyzer Operation.

Press and momentarily hold the **POWER ON/OFF** key. The computer will power up, show the firmware version, and go to the **==Live== Fan OFF** screen. When the fan is not operating, the sensor readings will not be accurate. Press the **SAMPLE** key. The display will read **= Sampling... =** until the sensor readings are stabilized - this may take a couple of minutes. Then the display will read **= Sampled Wthr =** when the sensors have correctly measured an air sample.

Display Example: *(use down arrow key to reveal more data)*

= Sampled Wthr =
72.3° 32 % 29.40" *(temp °F humidity % barometric pressure Inches Hg)*
Apr15 11:59:59pm *(date and time)*
STD Corr=1.0389 *(HP correction factor selected: STD or SAE)*
Dens Altd= 1686 *(density altitude ft)*
ADR= 95.2 *(air density ratio %)*
DryBaro= 29.139 *(dry barometric pressure Inches Hg)*
Dew Point= 40.7 *(dew point temp °F)*
Wet Bulb= 56 *(wet bulb temp °F)*
Vpr Prs= 0.257" *(water vapor pressure Inches Hg)*
Wtr Vpr=38.47Gr *(water vapor grains)*
Press Alt= 489 *(pressure altitude ft)*

The *RaceAir Pro* will put the current weather data in memory for automatic transfer into any of the programs that use weather information. The air sample data will be lost if the unit is turned off. The unit will also automatically turn off after 10 minutes of inactivity thereby losing the air sample data. Keeping a logbook record of run information and applicable weather information is recommended.

COMPUTER PROGRAMS OPERATION

Air Correction Program.

This program is used to calculate weather data from keyboard entries of temperature, relative humidity, and barometric pressure. Press **ALT** then **AIR CORR.** to start this program.

Display Example:

```

=== Air Corr ===
Temp?      71.0   (Enter temp °F)
Humidity?   31    (Enter humidity %)
AbsBaro?   30.24  (Enter barometric pressure Inches Hg)
STD Corr=  1.0079 (HP correction factor selected: STD or SAE)
Dens Altd=  630   (density altitude ft)
ADR=       98.2   (air density ratio %)
DryBaro=   30.000 (dry barometric pressure Inches Hg)
Dew Point= 39.1   (dew point temp °F)
Wet Bulb=  54    (wet bulb temp °F)
Vpr Prs=   0.241" (water vapor pressure Inches Hg)
Wtr Vpr=   36.03Gr (water vapor grains)
Press Alt= -294   (pressure altitude ft)

```

Tune-Up Information.

In order to use any of the *RaceAir Pro* jetting programs a baseline tune up, which includes a baseline air density ratio (ADR) and a baseline jet, must be established. Once the baseline tune up is established for a particular engine combination, the jet change programs will compute a change in the carburetor jets or the fuel injection bypass jet (pill) based on an air density change. The lower the air density is - the leaner the engine needs to be. The higher the air density is - the richer the engine needs to be.

CAUTION: When making any jet change, always monitor the engine exhaust gas temperature (EGT) indications, oxygen sensor (O2) readings, air/fuel ratio indication, etc., - most importantly, take spark plug readings to make sure the air/fuel mixture ratio does not become too lean. Severe engine damage can be caused by excessively lean mixtures.

Important: All the Computech Tune-Up Jetting programs require the use of flow tested jets. Modified jets or jets that are not flow tested do not have adequate fuel metering control for use with these programs.

To establish a baseline tune up, operate the engine at full throttle in typical racing conditions. Record the jet size (or sizes) used, the ADR, and any pertinent time or speed information. Now, lean the jet (or jets) down one size, make another full throttle run and repeat the process of recording the jet (or jets) size, ADR, plus time and/or speed information. Inspect the spark plugs, exhaust ports, etc. carefully for signs of detonation or other indications that the air/fuel mixture ratio may be too lean. Assuming there are no signs of being too lean and the vehicle picked up performance on the last run, repeat the entire procedure again with the jet (or jets)

one size leaner. Continue testing until the time and/or speed slows down or the engine shows signs of the air/fuel mixture ratio being too lean. At that point, richen the jet (or jets) 1 size when tuning for peak performance or 2 sizes when tuning for ET classes (bracket racing). The jet (or jets) and the ADR that you have at that time is the baseline tune up. Record the baseline tune up information for future reference.

All the Tune-Up Jetting programs provide jet suggestions that are more accurate than the jet size increments available. This is done so the user can easily see the exact fuel requirement for the measured ADR change from the baseline ADR. Select the actual jet closest to the suggested jet size while being careful not to run the engine overly lean - round the number up for carbureted applications or round the number down for fuel injection bypass systems.

Anytime the tune up is slightly rich or slightly lean, the **Adjust %** line can be used in any of the jetting programs to make adjustments to the tune up by changing engine fuel flow a few percent at a time. When the **Adjust %?** cursor block is flashing, press a number key corresponding to the desired engine fuel flow percent change (plus for richer, minus for leaner). For example, press **2** then **ENTER** for a 2% richer engine fuel flow or **2** then **-- (NO key)** then **ENTER** for a 2% (-2) leaner engine fuel flow. This tuning function can also be used when compensating for changes in the engine or vehicle combination, such as ignition timing, camshaft, carburetor, headers, fuel injection pump, fuel, etc.

Holley Jets.

Read the **Tune-Up Information** section before using this program. The Holley Jet change program is designed to work with Holley carburetor jets from #50 through #100. The program utilizes actual jet flows as opposed to drill sizes when making the computations. Use this program with the baseline tune up information to predict the proper jet to use as the ADR changes.

Important: Use only unmodified Holley flowed jets with this program. The Holley Jet program will not make accurate predictions for methanol or nitromethane fuels. The Precision Jet program can be used for carburetors with a single orifice main metering system using other than gasoline fuel.

Press the **SAMPLE** key and allow the weather analyzer to stabilize on the **= Sampled Wthr =** screen. Press **TUNE-UP** then **Jetting Menu** then **Holley** to start this program.

Display Example:

```

== Holley Jet ==
Base ADR?   95.7      (Enter ADR from baseline tune up)
New ADR?   99.2      (Press IMPORT WEATHER DATA to import ADR)
Base Jet?   88.0      (Press in baseline tune up jet number)
Adjust %?   0.0      (Enter tune up change, if needed)
New Jet#=   89.1      (Calculated new jet number)
    
```

Different size primary and secondary jets or staggered jet sizes can be quickly checked by using the **Recalculate Function**. See the **Program Access and Use** section for details.

Precision Jets.

Read the **Tune-Up Information** section before using this program. The Precision Jet program is designed to work with precision drilled/reamed and flowed jets. Hand drilled jets are not accurate enough for precise fuel metering. This program is designed to accept carburetor jet diameter in inches or millimeters. Make sure to enter the decimal point and zeros to denote the diameter dimension. It will work with any fuel. Use this program with the baseline tune up information to predict the proper jet to use as the ADR changes.

Press the **SAMPLE** key and allow the weather analyzer to stabilize on the = **Sampled Wthr** = screen. Press **TUNE-UP** then **Jetting Menu** then select **Prec Jets** to start this program.

Display Example:

```

== Prec. Jet ==
Base ADR?   95.7      (Enter ADR from baseline tune up)
New ADR?   99.2      (Press IMPORT WEATHER DATA to import ADR)
Base Dia?   0.032     (Press in baseline tune up jet size)
Adjust %?   0.0       (Enter tune up change, if needed)
New Dia=    0.033     (Calculated new jet size)
  
```

Mikuni Jets.

Read the **Tune-Up Information** section before using this program. This program is designed to accept Mikuni carburetor jet numbers. Use this program with the baseline tune up information to predict the proper jet to use as the ADR changes.

Press the **SAMPLE** key and allow the weather analyzer to stabilize on the = **Sampled Wthr** = screen. Press **TUNE-UP** then **Jetting Menu** then select **Mikuni Jets** to start this program.

Display Example:

```

== Mikuni Jet ==
Base ADR?   95.7      (Enter ADR from baseline tune up)
New ADR?   99.2      (Press IMPORT WEATHER DATA import ADR)
Base Jet?   150       (Press in baseline tune up jet size)
Adjust %?   0.0       (Enter tune up change, if needed)
New Jet=    155.3     (Calculated new jet size)
  
```

Keihin Jets.

Read the **Tune-Up Information** section before using this program. This program is designed to accept Keihin carburetor jet numbers. Use this program with the baseline tune up information to predict the proper jet to use as the ADR changes.

Press the **SAMPLE** key and allow the weather analyzer to stabilize on the = **Sampled Wthr** = screen. Press **TUNE-UP** then **Jetting Menu** then select **Keihin Jets** to start this program.

Display Example:

```

== Keihin Jet ==
Base ADR?   95.7      (Enter ADR from baseline tune up)
New ADR?   99.2      (Press IMPORT WEATHER DATA to import ADR)
Base Jet?   150       (Press in baseline tune up jet size)
  
```

Adjust %?	0.0	<i>(Enter tune up change, if needed)</i>
New Jet=	152.6	<i>(Calculated new jet size)</i>

Fuel Injection Jets, Area Method.

Read the **Tune-Up Information** section before using this program. This program is designed to work with mechanical fuel injection systems. The first time this program is used, all the engine fuel nozzle sizes must be entered in the setup. When the setup is completed the computer will remember the total nozzle area for future calculations. This program and the **Fuel Injection, High Speed Bypass Adjust** program use the same total nozzle area number from computer memory. Use this program with the baseline tune up information to predict the proper jet to use as the ADR changes.

Press the **SAMPLE** key and allow the weather analyzer to stabilize on the **= Sampled Wthr =** screen. Press **TUNE-UP** then **Jetting Menu** then select **Injection** to start this program.

Setup Display Example:

== Calc Area ==		<i>(Nozzle area setup routine)</i>
# Orifices?	8	<i>(Enter number of nozzles of this size)</i>
Diameter?	0.052	<i>(Enter nozzle diameter in inches)</i>
More?	Yes	<i>(Press ENTER to input more nozzles, NO to stop)</i>
# Orifices?	2	<i>(Enter number of nozzles of this size)</i>
Diameter?	0.020	<i>(Enter nozzle diameter in inches)</i>
More?	No	<i>(Press NO to stop)</i>

== Total Area ==		<i>(Total nozzle area screen)</i>
Area=	0.017618	<i>(Total nozzle area in square inches, RECORD this)</i>
Orifices=	10	<i>(Number of nozzles)</i>
Equiv Dia=	0.150	<i>(Single orifice diameter equivalent in inches)</i>
		<i>(Setup complete, press ENTER to continue)</i>

Injection Display Example:

== Select Jet ==		
Area=	0.017618	<i>(Total nozzle area square inches from memory)</i>
Base Pill?	0.065	<i>(Enter baseline main bypass jet diameter in inches)</i>
Bypass =	15.85	<i>(Calculated % of pump fuel being bypassed)</i>
Base ADR?	95.7	<i>(Enter ADR from baseline tune up)</i>
New ADR?	99.2	<i>(Press IMPORT WEATHER DATA to import ADR)</i>
BaseBoost?	0.00	<i>(Enter old blower manifold pressure PSI)</i>
New Boost?	0.00	<i>(Enter new blower pressure PSI)</i>
Adjust %?	0.0	<i>(Enter tune up change, if needed)</i>
Rail Chg=	5.2	<i>(High speed relief valve change + or - PSI)</i>
New Pill=	0.057	<i>(Calculated new main jet size)</i>

The next time the program is used, it is not necessary to repeat the setup portion. Press **TUNE-UP** then **Jetting Menu** then select **Injection** and **Select Jet**. The setup can be repeated anytime by selecting **Calc Area**.

Fuel Injection Jets, French Grimes' Method.

Read the **Tune-Up Information** section before using this program. This program has been designed by French Grimes, a well known expert in continuous flow fuel injection systems. It will work without knowing the injector nozzle sizes. Use this program with the baseline tune up information to predict the proper jet to use as the ADR changes.

Press the **SAMPLE** key and allow the weather analyzer to stabilize on the = **Sampled Wthr** = screen. Press **TUNE-UP** then **Jetting Menu** then select **F/G Injection** to start this program.

Display Example:

```

== F/G Inject ==
Fuel Pressure.....
  (0=Help)?    65      (Enter fuel rail pressure PSI)
Fuel=   Methanol      (Press down arrow to select fuel, ENTER)
Eng. CID?   410.0      (Enter engine displacement cubic inches)
Max RPM?   7500        (Enter peak engine RPM)
Base ADR?   95.7        (Enter ADR from baseline tune up)
New ADR?   99.2        (Press IMPORT WEATHER DATA to import ADR)
Base Jet?   0.060      (Enter baseline main bypass jet diameter in inches)
Adjust %?   0.0        (Enter tune up change, if needed)
Rail Chg=   2.0        (High speed relief valve change + or - PSI)
New Jet=   0.057      (Calculated new main jet size)
  
```

Fuel Injection, High Speed Bypass Adjust.

This program will calculate a high speed bypass (lean out) orifice diameter change for mechanical fuel injection systems. The program is based on a percentage of engine fuel being bypassed back to the fuel tank. It will calculate the current bypass percent and then size an orifice for a desired bypass change. The first time this program is used, all the engine fuel nozzle sizes must be entered in the setup. When the setup is completed the computer will remember the total nozzle area for future calculations. This program and the **Fuel Injection Jets, Area Method** program use the same total nozzle area number from computer memory.

Press **TUNE-UP** then **Jetting Menu** then select **High Speed** to start this program.

Setup Display Example:

```

== Calc Area ==      (Nozzle area setup routine)
# Orifices?    8      (Enter number of nozzles of this size)
Diameter?    0.028    (Enter nozzle diameter in inches)
More?        No      (Press NO to stop)

== Total Area ==      (Total nozzle area screen)
Area=    0.004926    (Total nozzle area in square inches, RECORD this)
Orifices=    8      (Number of nozzles)
Equiv Dia=    0.079  (Single orifice diameter equivalent in inches)
                          (Setup complete, press ENTER to continue)
  
```

High Speed Display Example:

```

== High Speed ==
Area=      0.004926      (Total nozzle area in square inches)
Main Pill?  0.060       (Enter baseline main bypass jet diameter in inches)
Old HSDia?  0.040       (Enter baseline HS bypass jet diameter in inches)
Old HS %=   16.21       (HS bypass % of engine fuel flow)
New HS %?   18.00       (Enter desired HS bypass %)
New HSDia=  0.042       (New HS bypass jet diameter)
  
```

Suggested changes to the high speed relief valve (poppet) pressure setting are presented in both the **Fuel Injection Jets** programs on the **Rail Chg=** program line. That line suggests that an increase (positive number) or decrease (negative number) be made to the relief valve cracking pressure (PSI) setting to maintain the same engine RPM operating point. This change is necessitated by the new main bypass jet and the resultant fuel rail pressure change.

Orifice Square Area.

This program will calculate the square area of round orifices such as jets, pills, or nozzles. Varied quantities and diameters are easily handled. An equivalent diameter for the total square area is also provided.

Press **TUNE-UP** then **Jetting Menu** then select **Square Area** to start this program.

Display Example:

```

== Calc Area ==
# Orifices?  1          (Enter number of orifices of this size)
Diameter?   0.028      (Enter orifice diameter in inches)
More?       No        (Press NO to stop)

== Total Area ==
Area=      0.000616    (Total area screen)
Orifices=   1          (Total orifice area in square inches)
Equiv Dia=  0.028     (Number of orifices)
                (Single orifice diameter equivalent in inches)
                (Press ENTER to continue)
  
```

Blower Overdrive.

This program calculates the percentage of overdrive between the blower and the crankshaft .

Press **TUNE-UP** then select **Blower OD** to start this program.

Display Example:

```

== Blower OD ==
BtmPulley?  65.0       (Enter bottom pulley teeth)
TopPulley?  51.0       (Enter top pulley teeth)
Overdrv=    27.5%      (Blower overdrive % or 127.5% of crankshaft RPM)
  
```

Gasoline Specific Gravity.

This program corrects the specific gravity readings of racing gasoline based on the temperature of the fuel. Hydrometer readings of the same fuel will vary with the temperature. The fuel supplier can provide the reference specific gravity and the reference temperature at which that specific gravity was taken. Knowing what the specific gravity reading should be at a given temperature will verify that the fuel is not degraded.

Press **TUNE-UP** then select **Gas. Spec.** to start this program.

Display Example:

==Gas Spec Grav=	
Ref SpGr? 0.7265	<i>(Enter factory reference specific gravity)</i>
Ref Temp? 60.0	<i>(Enter factory reference temp °F)</i>
Fuel Temp? 67.5	<i>(Enter measured fuel temp °F)</i>
SpecGrav= 0.7231	<i>(Specific gravity fuel should measure)</i>

Methanol Specific Gravity.

This program corrects the specific gravity readings of methanol (alcohol) racing fuel based on the temperature of the fuel. Methanol will absorb condensation inside a fuel container or moisture from the air. If moisture is present in a fuel sample the hydrometer reading will be higher than expected. Knowing what the specific gravity reading should be at a given temperature will verify that the fuel is not degraded.

Press **TUNE-UP** then select **Meth. Spec.** to start this program.

Display Example:

=Meth Spec Grav=	
Fuel Temp? 85.0	<i>(Enter measured fuel temp °F)</i>
SpecGrav= 0.7823	<i>(Specific gravity fuel should measure)</i>

Nitromethane Percent.

This program corrects the measured nitromethane content of a fuel sample for temperature. This program is designed to be used with special nitromethane hydrometers that are based on either a 60 or 68 degree Fahrenheit temperature standard. These hydrometers read in percent of nitro as opposed to the actual specific gravity.

Press **TUNE-UP** then select **Nitro %** to start this program.

Display Example:

= Nitro Percent =	
Hydro? 60	<i>(Enter hydrometer temperature standard)</i>
Fuel Temp? 78.0	<i>(Enter measured fuel temp °F)</i>
Nitro %= 85.0	<i>(Enter hydrometer measured nitro %)</i>
Corr Ntr%= 89.5	<i>(Corrected nitro %)</i>

Exhaust Gas Temperature Correction.

Monitoring cylinder exhaust gas temperatures (EGT) can assist in maintaining a consistent and repeatable tuneup. However, changes in engine inlet air temperature affects the exhaust gas temperature readings. Use this program to correct an observed exhaust gas temperature reading to a standard 60 degree Fahrenheit day. Then the **Exhaust Gas Temperature Prediction** program can be used to predict an indicated or observed EGT for a different air temperature.

Many things affect EGT (i.e. engine type and design, fuel mixture, ignition timing, engine RPM, thermocouple location, etc.). Typically, properly tuned methanol fueled engines will have a corrected EGT between 1050 and 1200 °F. The typical gasoline fueled engine EGT will be between 1250 and 1400 °F. These corrected EGT ranges are not necessarily ideal for your engine. The only way to find the desired EGT for a particular engine combination is by dyno testing or track testing. See the **Tune-Up Information** section for information on establishing a baseline tune up.

Press **TUNE-UP** then select **EGT Correct'** rto start this program.

Display Example:

```
=EGT Correction=
EGT?      1217      (Enter observed EGT °F)
Inlet Temp?  77      (Enter measured air temp °F)
Corr EGT=  1164      (Corrected EGT °F, RECORD this)
```

Exhaust Gas Temperature Prediction.

Use the **Exhaust Gas Temperature Correction** program first to obtain a corrected exhaust gas temperature (EGT). This program will predict what the indicated or observed EGT should be based on a previously recorded corrected EGT and the current engine inlet air temperature.

Press **TUNE-UP** then select **EGT Predict'** rto start this program.

Display Example:

```
=EGT Correction=
Corr EGT?  1164      (Enter recorded corrected EGT °F)
Inlet Temp?  77      (Enter measured air temp °F)
EGT=      1217      (Target observed EGT °F)
```


Dial-In, Standard Method.

This program is designed to help class and bracket racers predict an elapsed time (ET) for the next run based on changes in the horsepower correction factor. The Standard Dial-In method is Computech' s easiest to use and more accurate ET prediction program.

The correction factor method used can be changed from STD to SAE in the program setup area. The SAE method should produce more consistent results for large barometric pressure changes or different track elevations.

The program works for all length tracks and is compatible for use with either gasoline or methanol fuel. However, a setup fuel choice must be made to get accurate ET predictions. The program will automatically go to the fuel setup program during the first use.

The Dial-In is predicted from 1 previous reference run (no database of runs is used or required). The reference run, on which the prediction is based, is selected by the user. The reference run should be the most recent good full run when the vehicle performed as expected. Runs that had tire spin, unusual 60 ft times, or gusty wind conditions should not be used for the reference run. Change the run used as the reference (old) run as the race day progresses. It is important to use the most recent good full run as the reference. The most recent run will best represent the current traction and weather conditions.

This program works best when the engine fuel/air mixture is slightly rich so the vehicle performance will change appropriately with the weather changes. This may require periodic jet changes during the race season. The benefits gained in consistency and predictability are well worth the effort. If the vehicle runs quicker than the computer is predicting when the correction factor is improving (number getting smaller) then the fuel/air mixture is probably too rich and should be leaned slightly. Conversely, if the vehicle will not run as quick as the computer is predicting when the correction factor is improving then the fuel/air mixture is probably too lean and should be richened slightly. Efforts spent on getting the fuel/air mixture correct will be well worth the rewards in increased predictability. See the **Tune-Up Information** section for more details.

Press the **SAMPLE** key and allow the weather analyzer to stabilize on the = **Sampled Wthr** = screen. Press **DIAL-IN** then **Standard** to start this program.

Fuel Display Example:

```

== Fuel Setup ==
Fuel = Methanol      (Press down arrow to change fuel, then ENTER)
Done.                (Press CLEAR to return to program)
  
```

Std Dial-In Display Example:

```

==Std. Dial-In ==      (Press ALT, SET-UP, 1, 1 to change fuel)
Fuel = Methanol      (Fuel selected)
Old Corr? 0.9887     (Enter reference run correction factor)
Old ET? 8.829       (Enter reference run ET)
New Corr? 0.9792     (Auto transferred new correction factor)
New ET= 8.812       (Predicted new ET - recommend subtracting 0.003
                        from prediction for Dial-In of 8.80)
  
```

Dial-In, Density Altitude Method.

This program is designed to help class and bracket racers predict an elapsed time (ET) for the next run based on changes in the density altitude. This program requires that the **Dens Alt Setup** function be run for each vehicle so that the program can calculate an elapsed time versus density altitude ratio. The program has memory for 3 different data sets.

The Dial-In is predicted from 3 previous runs that are entered into the computer memory during the **Dens Alt Setup** program and a recent reference run. The reference run, on which the prediction is based, is selected by the user. The reference run should be the most recent good full run when the vehicle performed as expected. Runs that had tire spin, unusual 60 ft times, or gusty wind conditions should not be used for the reference run. Change the run used as the reference (old) run as the race day progresses. It is important to use the most recent good full run as the reference. The most recent run will best represent the current traction and weather conditions. Since this program utilizes runs from memory, it is compatible with whatever fuel being used.

This program works best when the engine fuel/air mixture is slightly rich so the vehicle performance will change appropriately with the weather changes. This may require periodic jet changes during the race season. The benefits gained in consistency and predictability are well worth the effort. If the vehicle runs quicker than the computer is predicting when the density altitude is improving (getting lower) then the fuel/air mixture is probably too rich and should be leaned slightly. Conversely, if the vehicle will not run as quick as the computer is predicting when the density altitude is improving then the fuel/air mixture is probably too lean and should be richened slightly. Efforts spent on getting the fuel/air mixture correct will be well worth the rewards in increased predictability. See the **Tune-Up Information** section for more details.

DA DIAL-IN SETUP. It is likely that several runs will need to be made to get 3 good runs for the setup. Record the run data for all the runs, including the density altitude. The runs you select should all be good, full runs with at least 100 feet of difference in density altitude between any two runs. This will allow the program to calculate the amount of elapsed time change the vehicle experiences in comparison to the respective change in the density altitude. The setup runs should be made on the same day, preferably in the same lane so that the traction conditions will be similar. Make sure the 60 foot times are within 0.01 seconds of each other. Also, verify that as the density altitude gets higher, the vehicle slows down. Conversely, as the density altitude gets lower the vehicle should go quicker.

The setup function may be run as often as you desire or whenever the accuracy of the program is not up to par. The entire setup routine must be repeated for each vehicle.

Important: When any change is made that might affect vehicle performance the setup program should be run again to assure accuracy. Remember, the **Density Altitude Dial-In** program predictions can only be as good as the information put into the setup.

Press **DIAL-IN**, select **Density Altd**, select **D.A. Setup** then select **1 Car #0** to start this program.

Setup Display Example:

```

=Dens Alt Setup=
Car #?      228      (Enter car or combination ID number)
Run 1 DA?   862      (Enter density altitude for run #1)
Run 1 ET?   8.921    (Enter ET for run #1)
Run 2 DA?   1020     (Enter density altitude for run #2)
Run 2 ET?   9.005    (Enter ET for run #2)
Run 3 DA?   1184     (Enter density altitude for run #3)
Run 3 ET?   9.109    (Enter ET for run #3)
.01 SEC=    17'      (ET change for density altitude change ratio)
                (Setup complete)

```

Press the **SAMPLE** key and allow the weather analyzer to stabilize on the = **Sampled Wthr** = screen. Press **DIAL-IN**, select **Density Altd**, then **1 Car #228** to start this program.

DA Dial-In Display Example:

```

=Dial-In Car#228
Last DA?    1291     (Enter reference run density altitude)
Last ET?    9.112    (Enter reference run ET)
New DA?     1220     (Auto transferred new density altitude)
New ET=     9.071    (Predicted new ET - recommend subtracting 0.003
                    from prediction for Dial-In of 9.06)

```

Throttle Stop Timer Settings.

This program is designed to help super class racers predict the throttle stop timer settings for the next run based on changes in the correction factor. The correction factor method used can be changed from STD to SAE in the program setup area. The SAE method should produce more consistent results for large barometric pressure changes or different track elevations. This program requires that the **T-Stop Setup** function be run for each vehicle or combination so the program can calculate an elapsed time versus throttle stop timer setting ratio. The program has memory for 3 different data sets.

The program works for all length tracks and is compatible for use with either gasoline or methanol fuel. However, a setup fuel choice must be made to get accurate timer predictions. The program will automatically go to the fuel setup program during the first use. The setup function must be redone if you change anything that affects vehicle performance.

The timer setting is predicted from 2 previous runs that are entered into the computer memory during the **T-Stop Setup** program and a recent reference run. The reference run, on which the prediction is based, is selected by the user. The reference run should be the most recent good full run when the vehicle performed as expected. Runs that had tire spin, unusual 60 ft times, or gusty wind conditions should not be used as the setup runs or the reference run. Change the run used as the reference (old) run as the race day progresses. It is important to use the most recent good full run as the reference. The most recent run will best represent the current traction and weather conditions.

The throttle stop program works best when the engine fuel/air mixture is slightly rich so the vehicle performance will change appropriately with the weather changes. This may require periodic jet changes during the race season. The benefits gained in consistency and predictability are well worth the effort. If the vehicle runs quicker than the computer is predicting when the correction factor is improving (number getting smaller) then the fuel/air mixture is probably too rich and should be leaned slightly. Conversely, if the vehicle will not run as quick as the computer is predicting when the correction factor is improving then the fuel/air mixture is probably too lean and should be richened slightly. Efforts spent on getting the fuel/air mixture correct will be well worth the rewards in increased predictability. See the **Tune-Up Information** section for more details.

T-STOP SETUP. Most current throttle stop systems utilize two timers in the same unit. Typically, the first timer allows the throttle to remain wide open for some period of time and the second timer controls the throttle closed time. This program assumes that, once adjusted, the first timer setting will remain constant. Any time the first timer setting is changed, this setup procedure must be repeated. The program also assumes that the more time put into the second timer, the slower the car will run (higher elapsed time).

The program needs data from 2 runs to calculate the relationship between the second timer setting and elapsed time. The setup runs should be made on the same day, preferably in the same lane so that the traction conditions will be similar. Make sure the 60 foot times are within 0.01 seconds of each other. Make 1 of these runs with a timer setting that will allow the vehicle to run approximately 0.1 seconds faster than the target index. The other run should be made with a timer setting that will cause the vehicle to run approximately 0.1 seconds slower than the target index. It is likely that several runs will need to be made to get 2 good runs for the setup. Record the run data for all the runs, including the correction factor and the timer setting. Then select the 2 runs that more closely represent the setup criteria.

The setup procedure may be run as often as desired or whenever the accuracy of the program is not up to par. The entire setup routine must be repeated for each vehicle or combination.

Important: When a change is made to the first timer setting or any change is made that might affect vehicle performance, the setup procedure should be performed again to assure accuracy. Remember, the **T-Stop** program predictions can only be as good as the information put into the setup.

Press **T-STOP**, select **T-Stop Setup** then select **1 Car #0** to start this program.

Setup Display Example:

```

==T-Stop Setup==
Fuel = Methanol           (Press down arrow to change fuel, then ENTER)
Car#?      228           (Enter car or combination ID number)
Run #1...
  ..Corr?   0.9875       (ENTER to go to next line)
  ..ET?     8.861        (Enter correction factor for run #1)
  ..Timer?  1.190       (Enter ET for run #1)
  ..Timer?  1.190       (Enter timer setting seconds for run #1)
Run #2...
  ..Corr?   0.9882       (ENTER to go to next line)
  ..ET?     9.109        (Enter correction factor for run #2)
  ..Timer?  1.770       (Enter ET for run #2)
  ..Timer?  1.770       (Enter timer setting seconds for run #2)
  
```

.01 ET= 0.0234 (ET change for timer change ratio)
(Setup complete)

Press the **SAMPLE** key and allow the weather analyzer to stabilize on the = **Sampled Wthr =** screen. Press **T-STOP**, then **1 Car #228** to start this program.

T-Stop Display Example:

=T-Stop Car #228
Fuel= Methanol (Fuel selected)
Old Tmr? 1.540 (Enter timer setting for reference run)
Old Corr? 0.9878 (Enter correction factor for reference run)
Old ET? 8.914 (Enter ET for reference run)
New Corr? 1.0004 (Auto transferred new correction factor)
New ET? 8.900 (Enter desired new ET)
New Tmr= 1.457 (New timer setting to run desired ET)

Gear Ratio, Drag.

This program will calculate the necessary gear ratio to obtain the desired finish line engine RPM while accounting for tire size and torque converter slip. This program works for 1/8 mile as well as 1/4 mile drag racing.

Press **DRAG FORMULAS**, then **Gear Ratio** to start this program.

Display Example:

== Est. ET/MPH==
Tire...
...Circum? 106.0 (Enter tire circumference inches - not diameter)
Trap MPH? 154.00 (Enter desired finish line MPH)
Trap RPM? 7800 (Enter desired finish line engine RPM)
Conv Slip? 800 (Enter estimated torque converter slip RPM)
Gear Ratio= 4.56 (Calculated gear ratio)

Engine Trap RPM, Drag.

This program calculates the estimated finish line engine RPM. The variables considered are: ring and pinion gear ratio, tire circumference (roll out), finish line MPH, and estimated torque converter or clutch slippage at the finish line. This program works for both 1/8 mile and 1/4 mile tracks.

Press **DRAG FORMULAS**, then **Trap RPM** to start this program.

Display Example:

== Est. ET/MPH==
Tire...
...Circum? 106.0 (Enter tire circumference inches - not diameter)
Trap MPH? 154.00 (Enter desired finish line MPH)
Gear Ratio? 4.56 (Enter rear end gear ratio)
Conv Slip? 800 (Enter estimated torque converter slip RPM)
Trap RPM= 7800 (Calculated finish line engine RPM)

Torque Converter Slip, Drag.

This program estimates the actual finish line torque converter or clutch slippage in RPM. The variables considered are: gear ratio, tire circumference (roll out), finish line MPH, and finish line RPM. This program works for both 1/8 mile and 1/4 mile tracks.

Press **DRAG FORMULAS**, then **ConverterSlip** to start this program.

Display Example:

```

== Est. ET/MPH==
Tire...
..Circum?  106.0      (Enter tire circumference inches - not diameter)
Trap MPH?  154.22     (Enter finish line MPH)
Trap RPM=   7825      (Enter finish line engine RPM)
Gear Ratio? 4.56      (Enter rear end gear ratio)
Conv Slip=   829       (Calculated torque converter slip RPM)
Pct Slip=   10.59%    (Calculated torque converter slip %)
  
```

Run Completer, Drag.

This program will predict what the elapsed time and MPH would have been on a run that was aborted prior to the finish line. In break-out classes it is common practice to lift off of the throttle or to brake the vehicle prior to the finish line in an effort to take only enough win light to get there first and to avoid the possibility of breaking out. This program utilizes the 1000 ft elapsed time, the 1/4 mile elapsed time, the 1/4 mile MPH from a previous full run, and the 1000 ft elapsed time from the aborted run.

To use this program for 1/8 mile racing, substitute the 330 ft elapsed time for the 1000 ft elapsed time, the 1/8 mile elapsed time for the 1/4 mile elapsed time, and the 1/8 mile MPH for the 1/4 mile MPH.

Press **ALT, RUN COMP.** to start this program.

Display Example:

```

= Run Completer=
Old...
Part ET?   5.774      (Enter 1000 ft ET from full run)
Full ET?   6.918      (Enter 1/4 mile ET from full run)
Full MPH?  194.30     (Enter 1/4 mile MPH from full run)
New...
Part ET?   5.638      (Enter 1000 ft ET from aborted run)
Est ET=    6.755      (Calculated 1/4 mile ET for aborted run)
Est MPH=   198.99     (Calculated 1/4 mile MPH for aborted run)
  
```

Standardized Performance, Drag, Full Run Times.

This program corrects the elapsed time and MPH for any run to the correction factor reference standard conditions (i.e. correction factor 1.0000). This allows comparison of runs, even runs made on different days, as if the weather conditions were the same for all the runs. Performance modifications can be realistically evaluated by removing the amount of change caused by the weather differences. The program uses the fuel selected in **ALT, SET-UP**,

Program Setup, Fuel Setup for the calculations.

Important: This program can be used with either the STD or SAE correction factor method. However, since the different methods have different reference standards, runs corrected with one method cannot be compared to runs corrected with the other. The **AIR CORR.** program can be used to input the actual weather conditions for a run and convert the correction factor number to the desired method. The SAE method should produce more consistent results for large changes in barometric pressure or temperature.

Press **ALT, DRAG PERF.**, then **Full Run Std** to start this program.

Display Example:

=== Full Run ===		
Fuel=	Gasoline	<i>(Press ALT, SET-UP, 1, 1 to change fuel)</i>
Corr?	0.9943	<i>(Enter recorded correction factor from run to standardize)</i>
ET?	6.918	<i>(Enter ET from run to standardize)</i>
MPH?	194.30	<i>(Enter MPH from run to standardize)</i>
Std ET=	6.931	<i>(Standardized ET for selected run)</i>
Std MPH=	193.93	<i>(Standardized MPH for selected run)</i>

Standardized Performance, Drag, Intermediate Times.

This program corrects all of the intermediate times for any run to the correction factor reference standard conditions (i.e. correction factor 1.0000). This allows comparison of runs, even runs made on different days, as if the weather conditions were the same for all the runs. Performance modifications can be realistically evaluated by removing the amount of change caused by the weather differences. The program uses the fuel selected in **ALT, SET-UP, Program Setup, Fuel Setup** for the calculations.

Important: This program can be used with either the STD or SAE correction factor method. However, since the different methods have different reference standards, runs corrected with one method cannot be compared to runs corrected with the other. The **AIR CORR.** program can be used to input the actual weather conditions for a run and convert the correction factor number to the desired method. The SAE method should produce more consistent results for large changes in temperature or barometric pressure.

Press **ALT, DRAG PERF.**, then select **Intermed. Run** to start this program.

Display Example:

==Intermed. Run =	
Fuel= Methanol	<i>(Press ALT, SET-UP, 1, 1 to change fuel)</i>
Corr? 0.9784	<i>(Enter recorded correction factor from run to standardize)</i>
60' ET? 1.083	<i>(Enter ET from run to standardize)</i>
Std ET= 1.088	<i>(Standardized ET for selected run)</i>
330' ET? 2.928	<i>(Enter ET from run to standardize)</i>
Std ET= 2.940	<i>(Standardized ET for selected run)</i>
660' ET? 4.445	<i>(Enter ET from run to standardize)</i>
Std ET= 4.464	<i>(Standardized ET for selected run)</i>
1000' ET? 5.774	<i>(Enter ET from run to standardize)</i>
Std ET= 5.798	<i>(Standardized ET for selected run)</i>
1320' ET? 6.918	<i>(Enter ET from run to standardize)</i>
Std ET= 6.947	<i>(Standardized ET for selected run)</i>

1/8 Mile Estimated HP.

This program computes the estimated engine flywheel horsepower based on 1/8 mile elapsed time and vehicle weight. The HP corrected for the weather conditions is also shown. Use both the 1/8 mile and the 1/4 mile HP estimates to show the effective HP at the different parts of the track.

Press **ALT, DRAG PERF.**, then select **Est. 1/8 HP** to start this program.

Display Example:

== Est. 1/8 HP ==	
1/8mi ET? 4.445	<i>(Enter 1/8 mile ET)</i>
Weight? 1677	<i>(Enter vehicle starting line weight in pounds)</i>
Est. HP= 966	<i>(Estimated flywheel HP)</i>
Corr? 0.9784	<i>(Enter correction factor at time of run)</i>
Corr. HP= 945	<i>(Estimated corrected HP)</i>

1/4 Mile Estimated HP.

This program computes the estimated engine flywheel horsepower based on 1/4 mile elapsed time and vehicle weight. The HP corrected for the weather conditions is also shown. Use both the 1/8 mile and the 1/4 mile HP estimates to show the effective HP at the different parts of the track.

Press **ALT, DRAG PERF.**, then select **Est. 1/4 HP** to start this program.

Display Example:

== Est. 1/4 HP ==	
1/4mi ET? 6.918	<i>(Enter 1/4 mile ET)</i>
Weight? 1677	<i>(Enter vehicle starting line weight in pounds)</i>
Est. HP= 1001	<i>(Estimated flywheel HP)</i>
Corr? 0.9784	<i>(Enter correction factor at time of run)</i>
Corr. HP= 979	<i>(Estimated corrected HP)</i>

Elapsed Time and MPH Estimate from HP.

This program calculates the estimated elapsed time and MPH for 1/8 and 1/4 mile drag runs. It is based on engine flywheel horsepower and vehicle weight. The program can be used to see what effect changes in the vehicle weight or available horsepower will have on elapsed time and MPH.

Press **ALT, DRAG PERF.**, then select **Est. ET/MPH** to start this program.

Display Example:

```

== Est. ET/MPH ==
Est. HP?      405      (Estimated flywheel HP)
Weight?      3250     (Enter vehicle starting line weight in pounds)
1/8mi ET=    7.405    (Estimated 1/8 mile ET)
1/8mi MPH=   95.84    (Estimated 1/8 mile MPH)
1/4mi ET=   11.662    (Estimated 1/4 mile ET)
1/4mi MPH=  116.88    (Estimated 1/4 mile MPH)
  
```

Gear Ratio, Circle.

This program will assist in selecting the proper final drive gear ratio based on the old engine RPM, the old tire circumference, the old gear ratio, the new engine rpm, and the new tire circumference.

Press **CIR.TRK. FORMULAS**, then **Gearing/Tires**, then select **Gear Ratio** to start this program.

Display Example:

```

== Gear Ratio ==
Old RPM?     7250     (Engine RPM was)
Old Tire?    89.00    (Tire circumference was inches - not diameter)
Old Gear?    5.13     (Final drive gear ratio was)
New RPM?     7500     (Desired engine RPM)
New Tire?    89.00    (Desired tire circumference inches - not diameter)
New Gear=    5.31     (Calculated gear ratio to use)
  
```

Engine RPM, Circle.

This program will calculate a new peak engine RPM based on the old engine rpm, the old tire circumference, the old gear ratio, the new tire circumference, and the new gear ratio.

Press **CIR.TRK. FORMULAS**, then **Gearing/Tires**, then select **Engine RPM** to start this program.

Display Example:

```

== Engine RPM ==
Old RPM?     7250     (Engine RPM was)
Old Tire?    89.00    (Tire circumference was inches - not diameter)
Old Gear?    5.13     (Final drive gear ratio was)
New Tire?    89.00    (Desired tire circumference inches - not diameter)
New Gear?    5.31     (Desired gear ratio)
  
```

New RPM= 7504 *(Calculated engine RPM for this combination)*

Tire Size, Circle.

This program will calculate the required tire circumference based on the old engine RPM, the old tire circumference, the old gear ratio, the new engine RPM, and the new gear ratio.

Press **CIR.TRK. FORMULAS**, then **Gearing/Tires**, then select **Tire Size** to start this program.

Display Example:

== Tire Size ==		
Old RPM?	7250	<i>(Engine RPM was)</i>
Old Tire?	89.00	<i>(Tire circumference was inches - not diameter)</i>
Old Gear?	5.13	<i>(Final drive gear ratio was)</i>
New RPM?	7500	<i>(Desired engine RPM)</i>
New Gear?	5.31	<i>(Desired gear ratio)</i>
New Tire=	89.05	<i>(Calculated tire circumference inches to use)</i>

Tire Stagger, Circle.

This program computes the required tire circumference for the inside drive tire based on the race track turn diameter, the circumference of the outside drive tire, and the center to center spacing of the drive tires.

Press **CIR.TRK. FORMULAS**, then **Gearing/Tires**, then select **Tire Stagger** to start this program.

Display Example:

== Tire Stagger ==		
Turn Dia?	950'	<i>(Enter track turn diameter feet)</i>
OutrCirc?	89.00	<i>(Outside tire circumference inches - not diameter)</i>
Tire Spec?	54.50	<i>(Center to center drive tire spacing inches)</i>
InnrCirc=	88.57	<i>(Calculated inside tire circumference inches)</i>

Chassis Setup by Percent.

This program computes the static weight to expect at each wheel of a vehicle for a given chassis setup based on the total vehicle weight, the desired left side weight distribution percentage, the desired rear weight distribution percentage, and the desired right front to left rear diagonal weight distribution percentage.

Press **CIR.TRK. FORMULAS**, then select **Chassis**, then **Setup by Pct** to start this program.

Display Example:

==Setup by Pct ==		
Car Wgt?	2250	<i>(Enter total vehicle weight in pounds)</i>
%Left?	58.2	<i>(Enter desired left bias %)</i>
%Rear?	47.0	<i>(Enter desired rear bias %)</i>
%Diagonal?	53.5	<i>(Enter desired right front to left rear bias %)</i>
Wgt LF=	649	<i>(Calculated left front scale indication in pounds)</i>
Wgt LR=	660	<i>(Calculated left rear scale indication in pounds)</i>
Wgt RF=	543	<i>(Calculated right front scale indication in pounds)</i>
Wgt RR=	397	<i>(Calculated right rear scale indication in pounds)</i>

Chassis Setup by Weight.

This program will calculate the total vehicle weight, the percentage of left side weight distribution, the percentage of rear weight distribution, and the percentage of right front to left rear diagonal weight distribution for a given chassis setup based on the actual wheel scale indications.

Press **CIR.TRK. FORMULAS**, then select **Chassis**, then select **Setup by Wgt** to start this program.

Display Example:

```

==Setup by Wgt ==
Wgt LF?      649      (Enter left front scale indication in pounds)
Wgt LR?      660      (Enter left rear scale indication in pounds)
Wgt RF?      543      (Enter right front scale indication in pounds)
Wgt RR?      397      (Enter right rear scale indication in pounds)
Car Wgt=     2249      (Calculated total vehicle weight in pounds)
%Left=       58.2      (Calculated left bias %)
%Rear=       47.0      (Calculated rear bias %)
%Diagonal=   53.5      (Calculated right front to left rear bias %)

```

Fuel Mileage, Circle.

This program is designed to compute fuel consumption during a race. It calculates the number of laps to the next required fuel pit stop, the current miles per gallon, and the required number of gallons to complete the race. A unique feature of this program takes into account the number of caution laps run between fuel stops and automatically compensates for the reduced fuel consumption during those caution laps. The program is broken down into two sections, the pre-race setup program and the actual race program.

Press **CIR.TRK. FORMULAS**, then select **Fuel Mileage**, then **New Race** to start this program.

Setup Display Example:

```

== New Race ==
Fuel(1=G,2=M)? 2      (Enter fuel type, 1 for gasoline, 2 for methanol)
Capacity?     22.0     (Enter fuel capacity gallons)
# Miles?      100.0    (Enter miles for race)
# Laps?       160      (Enter number of laps for race)
Caution Factor
  (0=none)? 0.280      (Press ENTER to continue)
  (Enter fuel SAVED on caution lap, 28%, as decimal)
Miles/Lap?   0.625    (Calculated miles per lap)
Setup Done...      (Press ENTER to continue)
Press CLEAR to      (Press ENTER to continue)
Return...         (Press CLEAR to continue)

```

Press **CIR.TRK. FORMULAS**, then select **Fuel Mileage**, then select **Next Stop** to start this program.

Next Stop Display Example:

```

== Fuel Stop ==
Last Stop was..                (Press ENTER to continue)
..lap=          0              (Laps since last stop, 0 for first stop, ENTER to continue)
This Stop is...                (Press ENTER to continue)
..lap=          42              (Enter lap number for this fuel stop)
Laps Since=     42              (Calculated laps since last fuel stop)
Caution Laps?  5              (Enter yellow laps since last fuel stop)
Eff.Laps=       40.6           (Equivalent green laps for fuel consumption)
Empty catch can                (Press ENTER to continue)
  Into can #1.                 (Reminder, put catch can fuel into can #1 before weighing)
Fuel can wgt...                (Press ENTER to continue)
..#1 Gross?     80.5           (Enter can #1 weight full of fuel)
..#2 Gross?     78.3           (Enter can #2 weight full of fuel)
..#1 Empty?     22.8           (Enter can #1 weight after fuel stop, include catch can fuel)
..#2 Empty?     42.1           (Enter can #2 weight after fuel stop)
Max laps ' till.                (Press ENTER to continue)
..Nxt Stp=      62.3           (Estimated green laps before next fuel stop)
Curr MPG=       1.77           (Calculated fuel mileage miles per gallon)
Gal. Needed to.                (Press ENTER to continue)
..finish=       41.7           (Estimated fuel required to end of race)
Stop Done...                    (Fuel stop completed, press ENTER)
Press CLEAR to                (Press ENTER to continue)
Return...                        (Press CLEAR to continue)

```

The **CIR.TRK. FORMULAS, Fuel Mileage, Same Stop** program can be used to recalculate all the fuel mileage information if an error occurred during the process or if the calculated data is lost.

Important: The **New Race** data must be entered before the first fuel pit stop for each race.

Liquid Weights.

This program will provide the weights of water, gasoline, and alcohol based on the number of gallons input.

Press **CIR.TRK. FORMULAS**, then select **Liquid Wgts** to start this program.

Display Example:

```

===Liquid Wgts===
Gallons?        1              (Enter number of gallons)
Water=          8.41lb         (Water weight pounds for US gallons)
Alky=           6.61lb         (Methanol weight pounds for US gallons)
Gas=            6.01lb         (Gasoline weight pounds for US gallons)

```

MPH.

This program is designed to calculate the actual vehicle speed in MPH using a 1:1 transmission ratio. The calculations are based on the tire circumference, the engine RPM, and the final gear ratio. This program assumes no wheel spin and no clutch slippage.

Press **CIR.TRK. FORMULAS**, then **Gearing/Tires**, then select **MPH Calc** to start this program.
Display Example:

```

=== MPH Calc ===
RPM?      7250      (Engine RPM)
GearRtio?  5.13      (Final drive gear ratio)
TireCirc? 89.00     (Tire circumference inches - not diameter)
MPH=      118.84    (Calculated MPH)
  
```

Compression Ratio, Values Known.

This program computes the true compression ratio of an engine. All important factors are considered including bore, stroke, boost pressure, deck height, gasket bore, gasket thickness, combustion chamber volume, and effective piston dome volume.

Press **ALT, ENGINE FORMULAS**, then **C/R Menu**, then **Calc Ratio** to start this program.
Display Example:

```

== Comp Ratio ==
Bore?      4.250     (Enter cylinder bore diameter inches)
Stroke?    3.750     (Enter crankshaft stroke inches)
Boost?     0.000     (Enter max manifold pressure PSI gage)
Deck Hgt?  0.020     (Enter TDC piston to block deck clearance inches -  

use negative number for piston above deck -0.020)
Gskt Vol?  0.000     (Enter head gasket volume CC, enter 0 if not known)
Calc Gskt Vol: (Press ENTER to continue)
  ..Bore?    4.275     (Enter head gasket bore diameter inches)
  ..Thck?   0.080     (Enter head gasket thickness inches)
  ..Vol=     18.80     (Calculated head gasket volume cubic centimeters)
Chamb Vol? 77.00     (Enter head combustion chamber volume CC)
Dome Vol?  8.30      (Enter piston dome popup volume CC)
Ratio=     10.46 :1    (Calculated engine compression ratio)
  
```

Compression Ratio, Find Combustion Chamber Volume.

This program computes the combustion chamber volume in cubic centimeters (CC) required to achieve a desired compression ratio.

Press **ALT, ENGINE FORMULAS**, then **C/R Menu**, then select **Calc Chamber** to start this program.

Display Example:

```

==Calc Chamber==
Bore?      4.250      (Enter cylinder bore diameter inches)
Stroke?    3.750      (Enter crankshaft stroke inches)
Boost?     0.000      (Enter max manifold pressure PSI gage)
Deck Hgt?  0.020      (Enter TDC piston to block deck clearance inches -
                        use negative number for piston above deck -0.020)
Gskt Vol?  12.600     (Enter head gasket volume CC, enter 0 if not known)
New C/R?   11.00     (Enter desired engine compression ratio)
Dome Vol?   8.30      (Enter piston dome popup volume CC)
Chamber=   78.20     (Calculated head combustion chamber volume CC
                        to achieve desired compression ratio)

```

Compression Ratio, Find Piston Dome Volume.

This program computes the effective piston dome volume in cubic centimeters (CC) required to achieve a desired compression ratio.

Press **ALT, ENGINE FORMULAS**, then **C/R Menu**, then select **Calc Dome** to start this program.

Display Example:

```

=== Calc Dome===
Bore?      4.250      (Enter cylinder bore diameter inches)
Stroke?    3.750      (Enter crankshaft stroke inches)
Boost?     7.500      (Enter max manifold pressure PSI gage)
Deck Hgt?  0.020      (Enter TDC piston to block deck clearance inches -
                        use negative number for piston above deck -0.020)
Gskt Vol?  12.600     (Enter head gasket volume CC, enter 0 if not known)
New C/R?   11.00     (Enter desired engine compression ratio)
Chamber?  78.200     (Enter head combustion chamber volume CC)
Use FLAT TOP
with 0.131 deck
or dome=   -25.70     (Use flat top piston and
                        piston down in bore dimension inches)
Dome Vol=  -25.70     (Press ENTER to continue)
                        (Calculated piston dome popup volume CC,
                        negative number indicates dished piston)

```

Compression Ratio, by Pouring Combustion Chamber.

This program will calculate the compression ratio of an assembled engine by pouring the cylinder full of light oil or alcohol through the spark plug hole. It assumes that the piston is at top dead center and the head gasket is installed.

Press **ALT, ENGINE FORMULAS**, then **C/R Menu**, then select **Pour Chamber** to start this program.

Display Example:

```

==Pour Chamber==
Bore?      4.250      (Enter cylinder bore diameter inches)
Stroke?    3.750      (Enter crankshaft stroke inches)
Boost?     0.000      (Enter max manifold pressure PSI gage)
Deck Hgt?  0.000      (Enter 0 for this line)
Gskt Vol?  0.001      (Enter 0.001 for this line)
Pour Vol?   87.4      (Enter poured volume measured CC)
Ratio=    10.97 :1    (Calculated engine compression ratio)

```

Compression Ratio, Find Piston Dome Volume by Pouring.

Use this program to calculate the piston dome volume for a piston when the popup size is not known. Install the piston, with rings, in the bore at a measured distance below the deck of the block. Next, attach a flat clear plastic plate over the cylinder. The plate should have 1 or 2 holes over the bore to fill the area above the piston with light oil or alcohol. Then measure the exact volume of fluid required to fill the entire void. The program will also work with available compression ratio tools that have an area above the piston notched for dome clearance. The tool will have a volume number marked on it to indicate the notched area volume. Provide this information to the computer to calculate the dome volume.

Press **ALT, ENGINE FORMULAS**, then **C/R Menu**, then select **Pour Dome** to start this program.

Display Example:

```

== Pour Dome ==
Bore?      4.250      (Enter cylinder bore diameter inches)
Deck Hgt?  0.400      (Enter measured piston flat to block deck inches)
Plate Vol?  0.000      (Enter 0 for flat plate or marked volume CC for tool)
Pour Vol?  86.700      (Enter poured volume measured CC)
Dome Vol=   6.3       (Calculated piston dome volume CC)

```

Cubic Inch Displacement, Values Known.

This program computes the displacement of an engine. Values considered are bore, stroke, and number of cylinders.

Press **ALT, ENGINE FORMULAS**, then select **C.I.D. Menu**, then **Calc C.I.D.** to start this program.

Display Example:

```

== Calc C.I.D. ==
Bore?      4.250      (Enter cylinder bore diameter inches)
Stroke?   3.750      (Enter crankshaft stroke inches)
No. Cyl?   8          (Enter number of cylinders)
C.I.D.=    425.6      (Calculated engine cubic inch displacement)
Liters=    6.97       (Calculated engine displacement CC/1000)
  
```

Cubic Inch Displacement, Find Cylinder Bore.

This program computes the cylinder bore diameter required to obtain a desired engine displacement.

Press **ALT, ENGINE FORMULAS**, then select **C.I.D. Menu**, then select **Calc Bore** to start this program.

Display Example:

```

== Calc Bore ==
C.I.D.?   358.0      (Enter desired engine cubic inch displacement)
Stroke?   3.480      (Enter crankshaft stroke inches)
No. Cyl?   8          (Enter number of cylinders)
Bore=     4.046      (Calculated cylinder bore diameter inches)
  
```

Cubic Inch Displacement, Find Crankshaft Stroke.

This program computes the crankshaft stroke length required to obtain a desired engine displacement.

Press **ALT, ENGINE FORMULAS**, then select **C.I.D. Menu**, then select **Calc Stroke** to start this program.

Display Example:

```

== Calc Stroke ==
C.I.D.?   358.0      (Enter desired engine cubic inch displacement)
Bore?     4.035      (Enter cylinder bore diameter inches)
No. Cyl?   8          (Enter number of cylinders)
Stroke=    3.500      (Calculated crankshaft stroke inches)
  
```


INDEX

<u>Subject</u>	<u>Page</u>	<u>Subject</u>	<u>Page</u>
Air Correction	17	Help, Additional	11
Air Density Ratio	11	High Speed Bypass	21
Air Good/Bad	14	Holley Jets	18
Air Sample	15	HP Correction, Dyno	9
Bad Air	14	HP, 1/4 Mile	32
Barometric Pressure, Absolute	12	HP, 1/8 Mile	32
Blower Overdrive	22	Keihin Jets	19
Bypass, High Speed	21	KeyBoard Functions	9
Calibration	15	Liquid Weights	36
Chassis Setup by Percent	34	Mikuni Jets	19
Chassis Setup by Weight	34	Mileage, Fuel	35
CID	40	MPH	37
CID, Bore	40	Nitro Percent	23
CID, Stroke	40	Orifice Square Area	22
Clock Set	8	Piston Dome Volume, Pour	39
Communication Port	10	Power Requirements	9
Compression Ratio	37	Precision Jets	19
Compression Ratio, Chamber	38	Pressure Altitude	13
Compression Ratio, Dome	38	Program Access and Use	10
Compression Ratio, Pour Chamber	39	Program Setup	8
Correction Factor	12	Program Updates	11
Correction Factor Setup	8	Relative Humidity	14
Cubic Inch Displacement	40	Reset, Factory	8
Date Set	8	Reset, Power Off	9
Density Altitude	13	Run Completer	30
Dew Point	13	Sample, Air	15
Dial-In, Density Altitude	26	Setup by Percent	34
Dial-In, Standard	25	Setup by Weight	34
Displacement, Cubic Inch	40	Specific Gravity, Gasoline	23
Dome Volume, Piston Pour	39	Specific Gravity, Methanol	23
Dyno HP Correction	9	Square Area	22
EGT Correction	24	Standard Performance, Full	30
EGT Prediction	24	Standard Performance, Inter.	31
Engine RPM, Drag	29	Throttle Stop	27
RPM, Drag	29	Tire Size, Circle	34
ET & MPH from HP	33	Tire Stagger	34
Fuel Injection, Area	20	Torque Converter Slip	30
Fuel Injection, French Grimes	21	Tune-Up Information	17
Fuel Injection, HS Bypass	21	Vapor Pressure	14
Fuel Mileage	35	Water Vapor	14
Fuel Setup	8	Weather Analyzer Operation	16
Gear Ratio, Circle	33	Weather Analyzer Overview	11
Gear Ratio, Drag	29	Weather Terms	11
Good Air	14	Weights, Liquid	36